

ⓓ **Montageanleitung:**

1. Montageort der Antenne und die Kabelverlegung planen (besonders bei Anwendung in Fahrzeugen)
2. Fahrzeugscheibe an der vorhergesehenen Befestigungsfläche fettfrei reinigen
3. Schutzfolie an der Antenne abziehen
4. Die Antenne wird jetzt in der ausgewählten Position auf die Glasscheibe mit ausreichendem Druck aufgeklebt.
5. Das Anschlusskabel im Fahrzeug verlegen und über die FME-Buchse die Verbindung zum Telefonsystem herstellen.
6. Die Antenne ist nun installiert und funktionsfähig.

ⓖⓑ **Mounting instructions:**

1. First carefully select the point of aerial installation (especially if installed in a car) and plan the cable wiring.
2. Remove all traces of grease on the window surface at the envisaged point of installation.
3. Peel the protective film off the aerial.
4. Apply adequate pressure to bond the aerial onto the glass pane at the selected position.
5. Conduct the connecting cable inside the vehicle and connect to the telephone system via the FME socket.
6. The aerial is now installed and fully functional.