

Universal-Fernbedienung

Codelist

Universal Remote Control

TV	03
VCR	09
DVD	12
STB	16
DVB-T	20
AUX	21

ACER 1484
 ACME 0013
 ADA 0008
 ADC 0012 0008 0012 0008
 ADMIRAL 0019 0108 0002 0001
 0047 0000
 ADYSON 0003
 AGAZI 0002
 AGB 0123
 AIKO 0003 0009 0004
 AIWA 0184 0248 0291
 AKAI 1410 0011 0086 0009
 0068 0004 0006 0008
 0051 0061 0088 0169
 0200 0133 0141 0069
 1914
 AKIBA 0011
 AKURA 0169 0074 0002 0009
 0011 0071
 ALBA 0028 0027 0009 0011
 0003 0068 0083 0169
 0047 0245 0248 0162
 0062 1914
 ALBIRAL 0037
 ALIEN 1914
 ALKOS 0164
 ALLORGAN 0157 0026
 ALLSTAR 0051
 ALTUS 0042 1915
 AMPLIVISION 0003
 AMSTRAD 0011 0009 0068 0074
 0002 0108 0071 0069
 0030 0123 0013
 ANAM 0009 0065 0109
 ANGLO 0009
 ANITECH 0009 0002 0043 0109
 ANSONIC 0009 0014 1914
 AOC 0134
 ARC EN CIEL 0126 0045 0139
 ARCAM 0003
 ARCELIK 1915
 ARCTIC 1915
 ARISTONA 0169 0051
 ARSTIL 1915
 ARTHUR MARTIN 0158
 ASA 0017 0110 0016 0018
 0000 0021
 ASBERG 0051 0043
 ASTRA 0009
 ASUKA 0011 0002 0003
 ATLANTIC 0169 0003 0051 0157
 ATORI 0009
 AUDIOSONIC 0009 0003 0169 0011
 0051 0139 0157 0090
 AUDIOTON 0003
 AUSIND 0043
 AUTOVOX 0003 0002 0101 0157
 0000 0125 0043 1914
 BAIRD 0111 0139 0245
 BANG & OLUFSON 0199 0000
 BARCO 0112
 BASIC LINE 0009 0011 0051 0245
 1914
 BASTIDE 0003
 BAUR 0169 0118 0076 0141
 0132
 BEKO 0042 0083 0034 0095
 1064 0007 1915
 BELSTAR 1914
 BEON 0169 0051
 BERLIN 1915
 BEST 0113
 BESTAR 0051 0245
 BINATONE 0003
 BLACK DIAMOND 0171 1914
 BLACK PANTHER LINE 0245
 BLACK STAR 0129
 BLAUPUNKT 0117 0202 0135 0008
 0022 0100
 BLOOM 0015 1914

BLOMBERG 1915
 BLUE SKY 1485 0156 0011 1914
 BLUE STAR 0120
 BONDSTEC 0129
 BOOTS 0003
 BPL 0120
 BRANDT 0127 0045 0022 0036
 0126 0139 0046
 BRION VEGA 0051 0169 0000
 BRITANNIA 0003
 BROKSONIC 0920
 BRUNS 0000 0007
 BSR 0131 0026
 BTC 0011
 BUSH 0028 0027 0032 0009
 0011 0019 0205 0039
 0051 0068 0169 0107
 0115 0131 0139 0167
 0245 0248 0024 0132
 0120 0062 1914
 CAPSONIC 0002
 CARREFOUR 0027
 CASCADE 0009
 CATHAY 0051 0169
 CENTRUM 0168 0205
 CENTURION 0051 0169
 CENTURY 0000
 CGE 0129 0047 0131 0043
 CIMLINE 0009 0028
 CITY 0009
 CLARIVOX 0169 0037
 CLATRONIC 0009 0011 0051 0002
 0083 0003 0129 0030
 0043
 COMBITECH 0248
 CONCORDE 0009
 CONDOR 0198 0051 0083 0003
 0245
 CONRAC 0038 1395
 CONTEC 0003 0009 0027 0030
 0029
 CONTINENTAL EDISON 0022 0111 0036 0045
 0126 0139 0046
 COSMEL 0009
 CPRTEC 0156
 CROSLEY 0129 0131 0000 0043
 CROSSWOOD 1914
 CROWN 0009 0169 0083 0047
 0051 0245 0121 0043
 1914
 CS ELECTRONICS 0011 0129 0003
 CTC 0129
 CTC CLATRONIC 0014
 CYBERCOM 0177 0038 0171 0002
 0009 0206 0205 0207
 0208 0210 0169 0042
 0044 0127 0047 0061
 0063 0067 0068 0103
 0107 0115 0154 0168
 0185 0228 0209 0343
 0924 0933 0248 0291
 CYBERMAXX 0177 0038 0171 0002
 0009 0206 0200 0205
 0207 0208 0210 0211
 0169 0015 0042 0044
 0047 0048 0049 0061
 0063 0067 0068 0087
 0103 0107 0115 0127
 0154 0155 0168 0170
 0185 0228 0229 0209
 0218 1005 0894 0343
 0924 0933 0248 0291
 CYBERTRON 0011
 CYTRON 0177 0038 0171 0002
 0009 0206 0200 0205
 0207 0208 0210 0211
 0169 0015 0042 0044
 0047 0048 0049 0061
 0063 0067 0068 0087
 0103 0107 0115 0127

IYAMA	0051	0068				
IMPERIAL	1414					
	0047	0051	0083	0129		
	0131	0021	0043			
INDESIT	0024	0101				
INDIANA	0051	0169				
INGELEN	0021					
INGERSOL	0009					
INNO HIT	0009	0011	0003	0004		
	0051	0169	0245	0093		
	0123	1914				
INNOVATION	0171	0111	0002	0009		
	0169	0061	0067	0068		
	0103	0107	0115	0154		
	0168	0177	0248	0291		
INTERBUY	0009	0129	0109			
INTERFUNK	0051	0129	0169	0139		
	0141	0000	0021			
INTERTRONIC	0894					
INTERVISION	0002	0003	0014	0109		
IRRADIO	0009	0011	0051	0169		
	0068					
ISUKAI	0011					
ITC	0003	0131				
ITS	0011	0051	0068	0120		
ITT	0061	0009	0143	0031		
	0133	0141	0021	0142		
	0132					
ITT/NOKIA	0133	0142	0021			
ITV	0169	0171	0009	0088		
	0245					
JEC	0164					
JVC	0051	0053	0027	0068		
KAISUI	0009	0011	0003	0120		
KAMOSONIC	0003					
KAMP	0003					
KAPSCH	0157	0021				
KARCHER	0169	0003	0009	0016		
	0037					
KENDO	0019	0014	0028	0108		
	0245	1914				
KENNEDY	0131	0157				
KENNEX	1914					
KINGSLEY	0003					
KING TV	0015					
KITON	1914					
KNEISSEL	0174					
KOLSTER	0051					
KONKA	0047	0068	0229	0011		
KORPEL	0051	0169				
KORTING	0000					
KOYODA	0009					
KTV	0003					
KURO	0121					
KYOTO	0037					
LEISURE	1915					
LENCO	0009	0245	1914			
LENOIR	0003	0009				
LESA	0129					
LEYCO	0169	0002	0004	0051		
	0026					
LG	0084	0119	0129	0149		
	0019	0003	0051	0088		
	0131	0169	0171	0009		
	0261	0093				
LIESENK	0169					
LIFE	0002	0009	0061	0067		
	0068	0103	0107	0111		
	0115	0154	0168	0169		
	0171	0177	0205	0291		
LIFETEC	0177	0038	0171	0002		
	0009	0206	0205	0207		
	0208	0210	0211	0169		
	0015	0042	0044	0047		
	0048	0049	0061	0063		
	0067	0068	0087	0103		
	0107	0115	0127	0154		
	0155	0168	0170	0185		
	0228	0229	0209	0218		
	1005	0894	0343	0924		
	0933	0248	0291	1914		
LOEWE	1399	0097	0098	0051		
	0169	0000				
LOGIK	0030					
LS ELECTRONIK	0042					
LUMA	0019	0169	0141	0157		
LUMATRON	0002	0171	0019	0088		
	0051	0074	0169	0107		
	0141	0157	0245	1914		
LUX MAY	0051					
LUXOR	0141	0019	0047	0003		
	0077	0138	0093	0132		
M+P	0133					
MAGNADYNE	0014	0129	0131	0169		
	0000	0123				
MAGNAFON	0003	0014	0043	0123		
MAGNUM	0002	0111	0009	0169		
	0171	0061	0067	0068		
	0103	0107	0115	0154		
	0168	0177	0200	0291		
MANDOR	0002					
MANESTH	0002	0169	0003	0028		
	0051					
MANHATTAN	1914					
MARANTZ	1482	0051	0169			
MARELLI	0000					
MARK	0051	0169				
MATSUI	0173	0099	0091	0027		
	0180	0028	0147	0003		
	0004	0009	0019	0051		
	0068	0101	0164	0169		
	0248	0113	0123	0013		
	0062	0026	0030			
MATSUSHITA	0065					
MAXMEDIA	0115					
MCMICHAEL	0041					
MEDIATOR	0051	0169				
MEDION	1419	1397	1395	1002		
	1001	0177	0038	0171		
	0002	0009	0206	1015		
	0200	0205	0207	0208		
	0210	0211	0169	0015		
	0042	0044	0047	0048		
	0049	0061	0063	0067		
	0068	0087	0103	0107		
	0115	0127	0148	0154		
	0155	0168	0170	0185		
	0228	0229	0209	0218		
	1005	0894	0343	0924		
	0933	0248	0291	1014		
	1914					
MELECTRONIC	0009	0016	0169	0018		
	0003	0036	0051	0068		
	0110	0115	0139	0021		
	0109					
MEMOREX	0009	0920				
MEMPHIS	0004	0009				
METZ	1398	0205	0058	0038		
	0201	0135	0107	0151		
	0152	0000	0075	1914		
NEUFUNK	1914					
MICROMAXX	0177	0038	0171	0002		
	0009	0206	0200	0205		
	0207	0208	0210	0211		
	0169	0015	0042	0044		
	0047	0048	0049	0061		
	0063	0067	0068	0087		
	0103	0107	0115	0127		
	0154	0155	0168	0170		
	0185	0228	0229	0209		
	0218	1005	0894	0343		
	0924	0933	0248	0291		
MICROSTAR	0177	0038	0171	0002		
	0009	0206	0200	0205		
	0207	0208	0210	0211		
	0169	0015	0042	0044		
	0047	0048	0049	0061		
	0063	0067	0068	0087		
	0103	0107	0115	0127		
	0154	0155	0168	0170		

	0185	0228	0229	0209					PATHE MARCONI	0022	0045	0126	0139
	0218	1005	0894	0343						0037	0046		
	0924	0933	0248	0291					PAUSA	0009			
MINERVA	1015	0101	0135						PERDIO	0004			
MINOKA	0051								PHILCO	0047	0129	0131	0000
MITSUBISHI	0000	0027	0030	0051						0043			
	0054	0057	0060	0098					PHILHARMONIC	0003			
	0101	0135	0205	0194					PHILIPS	0200	0088	0217	0202
MIVAR	0055	0083	0003	0093						0020	0169	0003	0041
	0123	0043								0181	0051	0083	0111
MORAVA	1914									0115	0131	0141	0154
MOTION	0043									0000	0043	0089	
MT LOGIC	0090								PHOCUS	0042	0095	1064	
MTC	0132								PHOENIX	0051	0169	0000	
MULTI SYSTEM	0169								PHONOLA	0051	0169	0000	
MULTITEC	1914								PIONEER	1482	1418	0010	0145
MULTITECH	0003	0009	0014	0019						0036	0051	0139	0169
	0169	0027	0045	0129						0021			
	0131	0043							PLANTRON	0002	0051		
MURPHY	0003	0133	0018						POPPY	0009			
NAD	0141								PORTLAND	0245			
NAIKO	0099								PRANDONI-PRINCE	0019	0141	0123	
NAONIS	0019	0108							PRECISION	0003			
NATIONAL	0064	0101							PRIMA	0009	0021		
NEC	1482	1483	0185	0027					PRINZ	0047			
	0056								PRO2	0177	0038	0171	0002
NECKERMANN	0003	0169	0008	0019						0009	0206	0200	0205
	0022	0051	0083	0118						0207	0208	0210	0211
	0132	0000								0169	0015	0042	0044
NEI	0051	0068	0169	0113						0047	0048	0049	0061
NEOVIA	1019									0063	0067	0068	0087
NESCO	0129									0103	0107	0115	0127
NEW WORLD	0011									0154	0155	0168	0170
NEWTECH	0009	0051								0185	0228	0229	0209
NEXIUS	0015									0218	1005	0894	0343
NICAMAGIC	0003									0924	0933	0248	0291
NIKKAI	0002	0003	0164	0004					PROFEX	0009	0141	0043	
	0011	0051	0169						PROFILO	0171			
NOBLIKO	0003	0014	0043						PROFI-TRONIC	0051			
NOGAMATIC	0139								PROLINE	0004	0051	0062	0194
NOKIA	0061	0143	0063	0141					PROSONIC	0161	0169	0003	0015
	0077	0133	0031	0021						0042	0088	0107	0200
	0132	0142								0068	0245		
NORDMENDE	1391	1392	1394	0111					PROTECH	0002	0003	0009	0169
	0127	0036	0045	0051						0014	0051	0129	0131
	0126	0139	0046	0000						0132	0113	0194	
	0021	0024							PROVIEW	1419	1002	1001	
NORDVISION	0169								PROVISION	0169	0171	0015	
OCEANIC	0141	1011	0142	0021					PYE	0169	0051	0068	
	1089								PYMI	0009			
OKANO	0083								QUADRO	0205	0194		
OKI	1909	1910	1911						QUASAR	0129			
ONCEAS	0003								QUELLE	0169	0205	0002	0003
ONWA	0069									0016	0022	0051	0129
ORBIT	0051									0131	0135	0141	0017
ORION	0099	0147	0159	0009						0018	0026	0030	
	0212	0028	0051	0154					QUESTA	0027			
	0169	0171	0920	0248					RADIOLA	0051	0169		
	0283	0123	0142	0030					RADIOMARELLI	0129	0000	0123	
	0013	0062	0075	0026					RADIONETTE	0016	0018		
	1914								RADIOTONE	0051	0007	0194	
ORMOND	0205								RANK	0017	0027		
OSAKI	0011	0002	0003	0004					RBM	0017			
	0074								RCA	0031			
OSO	0011								REDIFFUSION	0141			
OSUME	0004	0029							REVOX	0051	0169		
OTTO VERSAND	0003	0169	0008	0001					REX	0019	0002	0108	0157
	0027	0051	0076	0111						0021			
	0118	0131	0139	0141					RFT	0000	0007		
	0120	0121	0132						R-LINE	0051	0169		
PACIFIC	1914								ROADSTAR	0002	0009	0011	0245
PACKARD BELL	0204	0203								1914			
PAEL	0003								ROBOTRON	0000			
PALLADIUM	0003	0083	0012						RTF	0000			
PANAMA	0002	0003	0009						SABA	0127	0111	0126	0036
PANASONIC	0065	0067	0064	0197						0045	0139	0141	0245
	0072	0186	0101	0141						0142	0046	0000	0123
	0021	0151	0142	0124						0021	0194		
	0152								SACCS	0037			
PATHE CINEMA	0003	0083	0131	0037					SAISHO	0028	0002	0003	0009

	0248	0030	0123	0013	SUPERLA	0003			
SALORA	0019	0031	0047	0061	SUPERTECH	0118			
	0107	0108	0118	0131	SUPRA	0009			
	0138	0141	0093	0121	SUSUMU	0011			
	0128	0132	0021	1914	SUTRON	0009			
SAMBERS	1411	0014	0169	0043	SYDNEY	0003			
	0123				SYSLINE	0169			
SAMSUNG	0090	0105	0104	0009	TANDBERG	0157	0026		
	0051	0172	0083	0002	TANDY	0001	0003	0004	0011
	0160	0003	0004	0312		0133	0021		
	0030	0093	1004		TARGA	0185	1018	1003	1004
SANDRA	0003	0009			TASHIKO	0003	0019	0027	0041
SANSUI	0051	0920				0056	0128		
SANYO	0004	0006	0031	0003	TATUNG	0051	0003	0004	0169
	0027	0016	0018	0083		0123			
	0127	0160	0131	0029	TCM	1413	0177	0038	0171
	0030	0040	0043			0002	0009	0206	1015
SAVILLE	0248					1017	1119	0205	0207
SBR	0041	0169				0208	0210	0169	0042
SCHAUB LORENZ	0141	0202	0205	1003		0044	0047	0061	0063
	0168	0095	0015	0042		0067	0068	0103	0107
	1011	1020	1385	1386		0115	0127	0154	0168
	1387	1388	1389	1390		0185	0211	0228	0209
	0021	0142				1005	0343	0924	0933
SCHNEIDER	0177	0003	0169	0011		0248	0291		
	0051	0068	0131	0139	TEC	0003	0009	0129	0131
	0160	0245	0264	0071		0133			
	0125	1914			TD SYSTEM	1908			
SCHWAIGER	1024				TECHLINE	1914			
SEG	0171	0002	0205	0003	TECHNICA	1914			
	0169	0009	0014	0027	TECHNICS	0065			
	0088	0129	0131	1014	TECHNIKA	1916			
	0168	0043	1914		TECHNISAT	0088	0099	0154	
SEI-SINUDYNE	0014	0013	0021	0026	TECHNISSON	0042			
	0075	0123	0000		TECHWOOD	1914			
SEITECH	0015				TECNISON	1914			
SELECO	0019	0027	0131	0108	TELEAVIA	0022	0036	0045	0111
	0157	0021	1914			0126	0139		
SENCORA	0009				TELEFUNKEN	0166	0111	0127	0190
SENTRA	0164					0022	0035	0163	0101
SHARP	0001	0059	0005	0027		0102	0036	0050	0051
	0187	0188	0029			0052	0078	0108	0126
SHIVAKI	1914					0139	0079		
SHORAI	0026				TELETECH	0169	0009	0088	0129
SIAREM	0014	0131	0000	0123		0113	1914		
SICATEL	0037				TELETON	0003	0157	0118	0132
SIEMENS	0008	0022	0200	0135	TENSAI	0011	0168	0018	0051
	0029					0026	1914		
SIERRA	0051				TESLA	1914			
SIESTA	0160				TESMET	0051			
SILVER	0027				TEVION	0177	0038	0171	0002
SILVERCREST	1914					0009	0206	1015	0200
SINGER	0014	0131	0129	0228		0205	0207	0208	0210
	0000					0211	0169	0015	0042
SINUDYNE	0014	0131	0169	0028		0044	0047	0048	0049
	0015	0000	0075	0013		0061	0063	0067	0068
	0026					0087	0103	0107	0115
SKANTIC	0138	0021				0127	0154	0155	0168
SKYMASTER	0016					0170	0185	0228	0229
SKYWORTH	0228					0209	0214	0218	1005
SLIDING	0015					1016	0894	0343	0924
SOLAVOX	0092	0021				0933	0248	0291	1064
SONITRON	0006	0031				1914			
SONOKO	0009	0002	0169	0003	TEXET	0003			
	0051	0245			THOMSON	1393	0166	0127	0111
SONOLOR	0006	0021				0003	0022	0036	0045
SONTEC	0051	0169	0160			0176	0101	0102	0050
SONY	0165	0130	0183	0106		0051	0052	0126	0139
	0076	0027	0127	0009		0163	0185	0245	0046
	0004	0182	0029	0030	THORN	0004	0018	0169	0035
	0011	0014				0054	0111	0127	0141
SOUND & VISION	0051	0169				0164	0037		
SOUNDWAVE	0003	0009	0011	0051	TOKAI	0004	0051		
STANDARD	0245				TOKYO	0003			
	0169				TOPLINE	1914			
STARLIGHT	0120				TOMASHI	0120			
STENWAY	0019	0157	0021		TOSHIBA	1482	0117	0164	0189
STERN	1415	1015	0206			0027	0146	0017	0920
SUNGOO	0009	0026	0062			0082	1914		
SUNKAI	0009	0051			TOWADA	0131	0021		
SUNWOOD									

TRIUMPH	0013	0123	0082	
UHER	0051	0157	0021	0043
ULTRAVOX	0003	0014	0129	0131
	0133	0000		
UNITED	0088	0169		
UNITED QUICK STAR	0245			
UNIVERSUM	0102	0002	0016	0018
	0051	0061	0169	0083
	0110	0122	0129	0131
	0143	1914		
UNIVOX	0037			
VEON	1912	1913		
VESTEL	0215	1771	0019	0051
	0169	0171	0083	0092
	0103	0107	0118	0129
	0131	0138	0168	0195
	0205	0021	1014	1914
VEXA	0169	0009		
VICTOR	0027	0051	0065	
VIDEO SYSTEM	0051			
VIDEOCON	1412			
VIDEOLIGUE	0011	0003		
VIDEON	0248			
VIDEOSAT	0129			
VIDEOTON	1914			
VISIOLA	0003			
VISION	0051	1915		
VISOREX	0096			
VISTAR	0133			
VIVAX	0015	0042	1008	
VORTEC	0051	0169		
VOXSON	0019	0051	0108	0021
	0043	0000		
WALTHAM	0003	0133	0138	0037
WATSON	0051	0169	1914	
WATT RADIO	0003	0014	0131	0037
WEGA	0000	0027		
WEGAVOX	0015			
WELLTECH	0042			
WELTBlick	0051	0169		
WESTON	0131			
WHARFEDALE	0099			
WHITE WESTINGHOUSE	0169	0003	0014	0043
WILSON	1914			
WINDSOR	1914			
WORLD OF VISION	1021			
YAKUMO	1012			
YALOS	0000			
YINHE	1396			
YOKO	0009	0011	0051	0169
	0002	0003		
YORX	0011			
ZANUSSI	0019	0157	0108	

TV-VCR(COMBOS)

AIWA	0248	0291		
ALBA	0245	0248		
BAIRD	0245			
BASIC LINE	0245			
BESTAR	0245			
BLACK PANTHER LINE	0245			
BUSH	0245	0248		
COMBITECH	0248			
CONDOR	0245			
CROWN	0245			
CYBERCOM	0248	0291		
CYBERMAXX	0248	0291		
CYTRON	0248	0291		
DAEWOO	0245			
DAYTRON	0245			
DUAL	0248	0291		
ESC	0245			
GENERAL TECHNIC	0248			
GOLDSTAR	0261			
GOODMANS	0245	0283		
GRANDIN	0245			
HINARI	0248			
INNO HIT	0245			
INNOVATION	0248	0291		

ITV	0245			
KENDO	0245			
LENCO	0245			
LG	0261			
LIFE	0291			
LIFETEC	0248	0291		
LUMATRON	0245			
MAGNUM	0291			
MATSUI	0248			
MEDION	0248	0291		
MICROMAXX	0248	0291		
MICROSTAR	0248	0291		
ORION	0248	0283		
PORTLAND	0245			
PRO2	0248	0291		
PROSONIC	0245			
ROADSTAR	0245			
SABA	0245			
SAISHO	0248			
SAMSUNG	0312			
SAVILLE	0248			
SCHNEIDER	0245	0264		
SONOKO	0245			
STANDARD	0245			
TCM	0248	0291		
TEVION	0248	0291		
THOMSON	0245			
UNITED QUICK STAR	0245			
VIDEON	0248			

TV-DVD(COMBOS)

AKAI	[1082&1410]			
AUDIOSONIC	[1062&0090]			
BEKO	1064			
BROKSONIC	0920			
CYBERCOM	[0343&0228]	[0924&0210]		
	[0933&0228]			
CYBERMAXX	0894	[0343&0228]		
	[0924&0210]	[0933&0228]		
CYTRON	0894	[0343&0228]		
	[0924&0210]	[0933&0228]		
DUAL	[0343&0228]	[0924&0210]		
	[0933&0228]			
DURABRAND	[0933&0228]	[1085&1006]		
	[1085&1007]	[1086&1008]		
	[1087&1008]	[1088&1009]		
H&B	[0343&0228]			
HB	[1089&1011]			
GERICOM	1064			
INTERTRONIC	0894			
LIFETEC	0894	[0343&0228]		
	[0924&0210]	[0933&0228]		
MEDION	0894	[0343&0228]		
	[0924&0210]	[0933&0228]		
	1001			
MEMOREX	0920			
MICROMAXX	0894	[0343&0228]		
	[0924&0210]	[0933&0228]		
MICROSTAR	0894	[0343&0228]		
	[0924&0210]	[0933&0228]		
MT LOGIC	[1062&0090]			
OCEANIC	[1089&1011]			
ORION	0920			
PHILIPS	[0339&0181]			
PHOCUS	1064			
PRO2	0894	[0343&0228]		
	[0924&0210]	[0933&0228]		
PROVIEW	1001			
SANSUI	0920			
SCHAUB LORENZ	[1089&1011]			
TCM	[0343&0228]	[0924&0210]		
	[0933&0228]	1119		
TEVION	[0343&0228]	[0924&0210]		
	[0933&0228]	1064	0894	
TOSHIBA	0920			
VESTEL	[1771&0215]			

MURPHY	0231			
NATIONAL	0262	0260		
NEC	0294	0293	0299	
NECKERMANN	0257	0293	0301	
NEI	0257			
NESCO	0275			
NIKKAI	0250	0302		
NOKIA	0240	0300	0307	0258
	0237	0292	0293	
NORDMENDE	0294	0293	0303	0305
OCEANIC	0240	0231	0293	
OKANO	0233	0300		
ORION	0234	0233	0304	0248
	0283	0301	0246	
ORSON	0231			
OSAKI	0275	0231	0256	
OTTO VERSAND	0257			
PALLADIUM	0275	0300	0256	0271
	0293			
PANASONIC	0262	0267	0260	0314
	0321	0325	0970	
PATHE CINEMA	0301			
PATHE MARCONI	0293			
PENTAX	0266			
PERDIO	0231			
PHILCO	0299			
PHILIPS	0235	0257	0290	0315
	0327	0286	0285	0242
	0271	0293	0969	
PHONOLA	0257			
PIONEER	0294	0257	1084	
POLAROID	0949			
PORTLAND	0250	0245		
PRINZ	0231			
PRO2	0233	0311	0262	0269
	0319	0256	0248	0291
	0338	0905	0906	
PROFEX	0275			
PROLINE	0231	0288		
PROSONIC	0233	0245		
PYE	0257			
QUARTZ	0258			
QUELLE	0257	0263	0258	0231
	0271	0301		
RADIOLA	0257			
REX	0293			
RFT	0250	0257		
ROADSTAR	0275	0256	0245	
SABA	0324	0245	0281	0293
	0303	0305		
SAISHO	0275	0233	0248	0301
SALORA	0298	0258	0237	0292
SAMSUNG	0311	0312	0338	0963
SAMURAI	0250			
SANSUI	0294	0244	0293	0920
SANYO	0284	0258	0279	
SAVILLE	0248			
SBR	0257			
SCHAUB LORENZ	0258	0237	0231	0293
SCHNEIDER	0275	0233	0265	0250
	0257	0256	0231	0264
	0245			
SEG	0275	0319		
SEI-SINUDYNE	0257			
SELECO	0293			
SENTRA	0250			
SENTRON	0275			
SHARP	0240	0241	0328	0281
SHINTOM	0275	0258		
SHIVAKI	0256			
SIEMENS	0263	0256	0258	0271
SILVA	0256			
SILVERCREST	0256			
SINUDYNE	0257			
SOLAVOX	0250			
SONOKO	0245			
SONOLOR	0240			
SONTEC	0256			
SONY	0232	0308	0309	0310
	0313	0249	0251	0255
STANDARD	0402			
STRONG	0245			
SUNKAI	0244			
SUNSTAR	0233			
SUNTRONIC	0231			
SUNWOOD	0231			
SUNWOOD	0275			
SYLVANIA	0339	0231		
TAISHO	0233			
TANDBERG	0263			
TARGA	0256	0907	1041	
TASHIKO	0240	0231		
TATUNG	0257	0231	0293	
TCM	0233	0256	0311	0262
	0269	0319	0375	0248
	0291	0338	0905	0906
TEC	0250			
TECHNICS	0262	0260		
TELEAVIA	0293			
TELEFUNKEN	0306	0294	0324	0295
	0323	0280	0293	0303
	0305			
TENOSAL	0275			
TENSAI	0275	0231	0256	
TEVION	0233	0311	0262	0269
	0319	0256	0248	0291
	0338	0905	0906	
THOMSON	0294	0324	0295	0323
	0326	0245	0242	0293
	0305			
THORN	0258	0293	0301	
TIVO	0242			
TOKAI	0275	0256		
TONSAI	0275			
TOSHIBA	0320	0257	0265	0298
	0319	0362	0293	
TOWADA	0275			
TOWIKA	0275			
TRIUMPH	0301			
TVA	0250			
UHER	0256			
UNITED QUICK STAR	0245			
UNIVERSUM	0290	0235	0263	0257
	0315	0256	0231	0237
	0239	0253	0271	
VICTOR	0294	0295		
VIDEON	0233	0262	0311	0248
WELTBlick	0256			
YAMISHI	0275			
YOKAN	0275			
YOKO	0275	0250	0256	
ZENITH	0256			
TV-VCR(COMBOS)				
AIWA	0248	0291		
ALBA	0245	0248		
BAIRD	0245			
BASIC LINE	0245			
BESTAR	0245			
BLACK PANTHER LINE	0245			
BUSH	0245	0248		
COMBITECH	0248			
CONDOR	0245			
CROWN	0245			
CYBERCOM	0248	0291		
CYBERMAXX	0248	0291		
CYTRON	0248	0291		
DAEWOO	0245			
DAYTRON	0245			
DUAL	0248	0291		
ESC	0245			
GENERAL TECHNIC	0248			
GOLDSTAR	0261			
GOODMANS	0245	0283		
GRANDIN	0245			
HINARI	0248			
INNO HIT	0245			
INNOVATION	0248	0291		
ITV	0245			

KENDO	0245
LENCO	0245
LG	0261
LIFE	0291
LIFETEC	0248 0291
LUMATRON	0245
MAGNUM	0291
MATSUI	0248
MEDION	0248 0291
MICROMAXX	0248 0291
MICROSTAR	0248 0291
ORION	0248 0283
PORTLAND	0245
PRO2	0248 0291
PROSONIC	0245
ROADSTAR	0245
SABA	0245
SAISHO	0248
SAMSUNG	0312
SAVILLE	0248
SCHNEIDER	0245 0264
SONOKO	0245
STANDARD	0245
TCM	0248 0291
TEVION	0248 0291
THOMSON	0245
UNITED QUICK STAR	0245
VIDEON	0248

DVD-VCR(COMBOS)

APEX	0949
BROKSONIC	[0920&0967]
CINEVISION	[0375&0256]
CYBERCOM	0338 [0375&0256]
CYBERMAXX	0338 0896 0906 [0375&0256]
CYTRON	0338 0896 0906 [0375&0256]
DAEWOO	0971
DUAL	0338 [0375&0256]
EMERSON	[0339&0231] [0375&0256]
FUNAI	[0339&0231]
GO-VIDEO	0338 0367 0971
GOLDSTAR	[0375&0256]
HITACHI	[0387&0231]
JVC	0400
LG	0907 [0375&0256]
LIFETEC	0338 0896 0906 [0375&0256]
MAGNAVOX	[0914&0285]
MEDION	0338 0896 0906 [0375&0256]
MICROMAXX	0338 0896 0906 [0375&0256]
MICROSTAR	0338 0896 0906 [0375&0256]
PANASONIC	0970
PHILIPS	[0969&0285]
PIONEER	1084
POLAROID	0949
PRO2	0338 0896 0906 [0375&0256]
SAMSUNG	0338 0963
SANSUI	0920
SANYO	[0378&0258]
SILVERCREST	0256
SONY	0402
SYLVANIA	[0339&0231]
TARGA	[0375&0256] 0907 [0375&1041]
TCM	0338 [0375&0256]
TEVION	0338 0896 0906 [0375&0256]
TOSHIBA	0362
ZENITH	[0375&0256]

ACCOUSTIC SOLUTIONS	0383	0350			0330	0335	0339	0340	
AEG	0894	0333			0341	0342	0345	0352	
AFREEY	0386				0358	0371	0380	0895	
AIRIS	0357				0896	0897	0898	0899	
AIWA	0383	0377			0900	0901	0902	0903	
AKAI	0369	0333	0382	0350	0904	0923	0893	0959	
	0894	1082			1069	1070	1071	1067	
AKASHI	0346				1066	1068	1117	1118	
ALBA	0384	0350	0381	0357	0905	0343	0924	0933	
	0370	0351			0375	0906	0338	0372	
ALL-TEL	0333				0334	0344	0664	0894	
AMES	0383				CYBERVISION	1791			
AMSTRAD	0350				DAEWOO	0353	0354	0965	0355
AMW	1053	1054				0347	0380	0925	0971
ANABA	0961				DANSAI	0351			
ANSONIC	0356				DAYTRON	0925			
APEX	0921	0384	0357	0911	DCE	0356			
	0390	0913	1083	0949	DENON	0364	0389		
ARENA	0923				DENVER	0381	1051	0894	
ASPIRE	0952				DENZEL	0392			
A-TREND	0347				DESAY	0958			
AUDIOSONIC	0382	1062			DIAMOND	0373	0341		
AUDIOVOX	0942				DIGIFRAME	0930			
AXION	0942				DIGIHOME	0350			
B & K	0978				DIGITOR	0382			
BAIER	0349				DIGITREX	0357			
BAZE	0357				DIGITRON	0386			
BEKO	1064				DIGIX	0962			
BLACK DIAMOND	0350				DIK	0356			
BLAUPUNKT	0384				DISNEY	0339	0902		
BLU-RAY	1796	1109	1108	1107	DIVIDO	0380			
	1113	1081	0375		DIVX	0375	0932		
BLUE NOVA INTERNATIONAL	1051				DK DIGITAL	0356			
BLUE SKY	0375	0373	0357	0350	DMTECH	0351	0333		
BOMAN	0894	0351			DRAGON SYSTEMS	0356			
BRANDT	0373	0360	0362		DUAL	0350	0356	0984	0383
BRITANIA	1795					0956	0373	0330	0335
BROKSONIC	0920	0967				0337	0340	0392	0341
BUSH	0384	0382	0350	0381		0342	0345	0352	0358
	0356					0371	0923	0351	0333
CAMBRIDGE	0376					0343	0338	0372	0334
CELESTIAL	0357					0344	0664	0375	0924
CENTREX	0357					0933			
CENTRIOS	0932	0951	0954	0955	DURABRAND	0333	0375	0356	0933
CENTRON	0932					1085	1086	1087	1088
CENTRUM	0346	0926	0928	0350	DUNE	1901	1902		
	0927				DVD	1024	0929		
CINETEC	0350				E-BENCH	0341			
CINEVISION	0375				ELTA	0365	0382	0894	0333
CLASSIC	0383				ELTAX	1051			
CLATRONIC	0357	0894			EMERSON	0380	1057	0339	0375
CMI	0923				ENCORE	0386			
COBY	0332	0916	0946	0947	ENZER	0392			
	0357	1051	0948		ESA	0956			
CONTEL	1772	0894			EUROLINE	0894			
CRITERION	0344				FARENHEIT	0960			
CROWN	0373	0382			FERGUSON	0373			
C-TECH	0341				FINLUX	0375	0357	0351	
CURTIS	0950	0948			FINTEC	0350			
CYBERCOM	0356	0930	0932	0330	FIRSTLINE	0373			
	0335	0339	0340	0341	FISHER	0378			
	0342	0345	0352	0358	FUNAI	0339			
	0371	0923	0375	0343	GE	0384			
	0924	0933	0338	0334	GERICOM	1064			
	0344	0664	0372	0373	GOLDEN SPHERE	0341			
CYBERHOME	0347	0912	0985	1075	GOLDSTAR	0375	0907	0972	
CYBERLINK	1101				GOODMANS	0373	0382	0350	0333
CYBERMAXX	0356	0930	0373	0932		0351			
	0330	0335	0339	0340	GO-VIDEO	0383	1059	1061	0338
	0341	0342	0345	0352		0367	0971	0351	
	0358	0371	0895	0896	GPX	0910			
	0897	0898	0899	0900	GRADIENTE	1794	1793	0373	
	0901	0902	0903	0904	GRAETZ	0392			
	0923	0893	0959	1069	GRAN PRIX	0356			
	1070	1071	1067	1066	GRANDIN	0357			
	1068	1117	1118	0905	GRUNDIG	0385	0370	0380	0373
	0343	0924	0933	0375		0378	0376	0350	0333
	0906	0338	0372	0334	H & B	0350	0343		
	0344	0664	0894		HB	1095	1089		
CYTRON	0356	0930	0373	0932	HAAZ	0341	0342		

HANSEATIC	0375	0351	0333					0342	0345	0352	0358	
HARMON/KARDON	0395							0371	0351	0895	0896	
HCM	0894							0897	0898	0899	0900	
HD-DVD	1796	1110	1109	1108				0901	0902	0903	0904	
	1107	1081	0375					0923	0893	0959	1069	
HE	0383							1070	1071	1067	1066	
HITACHI	0367	0368	0392	0387				1068	1115	1116	1117	
	0350							1118	0905	0343	0924	
HITEKER	0357							0933	0375	0906	0338	
HOHER	0356							0372	0334	0344	0664	
HOME ELECTRONICS	0383							0894				
HOMITA	0934	0935	0936	0937				MEMOREX	0356	0339	0920	
	0938							MERIDIAN	0362			
HOYO	0392							METZ	0368	0350	0922	
HYUNDAI	0351							MICROMAXX	0356	0893	0930	0373
ILO	0959								0932	0330	0335	0339
INITIAL	0384								0340	0341	0342	0345
INTEGRA	0374								0352	0358	0371	0895
INTERTRONIC	0893	0933	0894						0896	0897	0898	0899
JATON	0392								0900	0901	0902	0903
JBL	0395								0904	0923	0959	1069
JDB	0383								1070	1071	1067	1066
JVC	0361	1058	0362	0400					1068	1117	1118	0905
	0964	0662	1072						0343	0924	0933	0375
	1076	1083							0906	0338	0372	0334
JWIN	0351								0344	0664	0894	
KARCHER	0333							MICROMEGA	0370			
KAWASHI	0356	0923	0350					MICROSOFT	0399	1100		
KENDO	0350							MICROSTAR	0356	0930	0373	0932
KENNEX	0393	0364							0330	0335	0339	0340
KENWOOD	0392								0341	0342	0345	0352
KISS	0384								0358	0371	0895	0896
KLH	0908	0909							0897	0898	0899	0900
KONKA	0358	0373							0901	0902	0903	0904
KOSS	0341								0923	0893	0959	1069
LASONIC	0341	0380							1070	1071	1067	1066
LAWSON	0376								1068	1117	1118	0905
LECSON	1774	0373	0350	0356					0343	0924	0933	0375
LENCO	0931	0346	0382						0906	0338	0372	0334
LENOXX	1800	1798	1797	1117					0344	0664	0894	
LG	0375	0907	0972					MINATO	0349			
LIFE	0900	0373	1117	1118				MINERVA	0380			
	0372							MINTEK	0384			
LIFETEC	0356	0930	0373	0932				MIRROR	0349			
	0330	0335	0339	0340				MITSUBISHI	0350	0366		
	0341	0342	0345	0352				MONYKA	0392			
	0358	0371	0895	0896				MT LOGIC	1062			
	0897	0898	0899	0900				MUSTEK	0383			
	0901	0902	0903	0904				MXONDA	0373			
	0923	0893	0959	1069				MYSTRAL	0356			
	1070	1071	1067	1066				NAD	0375	0394		
	1068	1117	1118	0905				NAKAMICHI	0398			
	0343	0924	0933	0375				NEC	0375			
	0906	0338	0372	0334				NEOTEK	0386			
	0344	0664	0894					NEUFUNK	0392			
LIMIT	0341							NEVIR	0356			
LINN	0336							NEXXTECH	1772	0932	0954	0955
LITEON	0982	1056	1059	0959					0956			
LODOS	0350							NORCENT	0332	0982	0944	0945
LOEWE	0370	0375							0948			
LOGIX	0351	0380						NORDMENDE	0356			
LUMATRON	0332	0342	1051	0350				NORIKO	0349			
	0383	0380						OCEANIC	1089			
LUXMAN	0367							OKANO	0349	0362		
LUXOR	0350	0383						OMNI	0382			
MAGNAVOX	0362	0379	0979	0980				ONIX	0346			
	0981	0370	0350	0914				ONKYO	0374	0975		
MANHATTAN	0350	0380						OPTIMUS	0368	0922		
MARANTZ	1079	0370	0379	0981				ORION	0920	0335		
	0375	0362						ORITRON	0373			
MARK	0350							PACIFIC	0356	0350	0333	
MASTEC	0335							PACKARD BELL	0939	0940	1101	1052
MATSUI	0373	0357	0350					PALSONIC	0357			
MAXDORF	0894							PANASONIC	1107	0401	0364	0403
MAXIM	0331	0350							0970	0974		
MBO	0396	0383	0382					PANDA	0351			
MEDIENCOM	0342							PHILCO	1792			
MEDION	1800	1798	1001	0356				PHILIPS	1775	0370	0379	0979
	0930	0373	0932	0330					0980	0981	0362	1080
	0335	0339	0340	0341					1123	1128	0969	0339

PHOCUS	1063	1064		
PHONOTREND	0916			
PIONEER	1109	1108	0368	0977
	0922	0968	0976	1084
POLAROID	0957	0949		
PORTLAND	0382			
PRINZ	0356			
PRISM	0335			
PRO2	0356	0930	0373	0932
	0330	0335	0339	0340
	0341	0342	0345	0352
	0358	0371	0895	0896
	0897	0898	0899	0900
	0901	0902	0903	0904
	0923	0893	0959	1069
	1070	1071	1067	1066
	1068	0905	0343	0924
	0933	0375	0906	0338
	0372	0334	0344	0664
	0894			
PROCASTER	0905			
PROLINE	0373	0357	0333	0376
	0397			
PROSCAN	0399			
PROSON	0350			
PROSONIC	0332	0341	0349	
PROVIEW	1001			
PROVISION	0381	1051		
QUADRO	0928			
QUARTEK	1077			
RADIONETTE	0375			
RAITE	0392			
RCA	0399	0384		
REDSTAR	0894	0965		
RELISYS	0923	0895		
REOC	0341			
REX	0346			
ROADSTAR	0350	0383	0382	
RONIN	0397			
ROTEL	0361			
ROWA	0384	0922		
RTL	0923			
SABA	0373	0915	0360	
SAIVOD	0356			
SALORA	0375			
SAMPO	0341	0386	0923	0895
	1051			
SAMSUNG	1122	1114	1113	1112
	0367	1050	0338	0963
	0919			
SANSUI	0341	0920		
SANYO	0350	0333	1060	0378
SCAN	0380			
SCHAUB LORENZ	1095	0894	1089	
SCHNEIDER	0350	0352	0356	0373
	0351	0894	0333	0380
SCHWAIGER	0349			
SCIENTIFIC LABS	0341			
SCOTT	0373	0357		
SEG	0350	0341	0392	
SHARP	1796	0371	0394	1055
	0350			
SHERWOOD	0391			
SHINCO	0384			
SHINSONIC	0384			
SILVA	0894			
SILVA SCHNEIDER	0356			
SILVERCREST	0341	1093	1090	1091
	1092			
SINGER	0341	0382		
SKYMASTER	0382	0383		
SM ELECTRONIC	0382	0383	0341	
SMART	0350	0380		
SONY	1081	0363	0987	0988
	0989	0402	0986	
SOUNDMASTER	0341			
SOUNDMAX	0341			
SOUNDSTORM	0330			
SOUNDWAVE	0351			
STANDARD	0373			
STRONG	0350			
SUNGALE	0953			
SUPERVISION	0382	0383		
SVA	0349			
SYLVANIA	0339			
SYNN	0341			
TANDBERG	0350			
TANGENT	1051			
TARGA	0375	1115	0959	0891
	1117	0972	1094	1121
	0907			
TCM	0900	0356	0930	0373
	0932	0330	0335	0339
	0340	0333	0341	0342
	0345	0352	0358	0371
	0923	1119	0343	0924
	0933	0338	0372	0334
	0344	0664		
TEAC	0368	0333	0341	0384
	0375			
TECHNICS	0364	0399		
TECHNIKA	0356			
TECHWOOD	0394	0350	0370	
TECO	0923	0895		
TEDELEX	0382			
TELEDEVICE	1051			
TELEFUNKEN	0894	0333		
TELETECH	0350			
TENSAI	0373	0382		
TERAPIN	0943			
TEVION	0356	0930	0373	0932
	0330	0335	0337	0339
	0340	0341	0342	0345
	0352	0358	0371	0891
	0892	0895	0896	0897
	0898	0899	0900	0901
	0902	0903	0904	0923
	0966	0893	0959	1065
	1068	1069	1070	1071
	1067	1066	1117	1118
	0890	0905	0343	0924
	0933	0375	0906	0338
	0917	0918	0372	0334
	0344	0664	0894	1064
THETA DIGITAL	0368			
THOMSON	0360	0359	0399	1078
TINY	1051			
TOKAI	0894	0392		
TOKIWA	0380			
TOSHIBA	0973	1110	1120	0362
	0983	0920	1111	
TRANS-CONTINENTS	0356	1051		
TRANSONIC	0357			
TREDEX	0941			
TRUTECH	1075			
UMAX	0382			
UNITED	0333	0348	0357	0894
UNIVERSUM	0350	0375	0333	
VENTURER	0333			
VESTEL	1771	0350		
VIETA	0380			
VOXSON	0383	0356	0382	
WALKVISION	0384			
WELKIN	0356			
WELLTECH	1098	1105	1106	
WESTAR	0350			
WHARFEDALE	0376	0349	0341	0386
WILSON	0356			
X-BOX	0399			
XENIUS	0373	0358		
XLOGIC	0341			
XMS	0894			
YAKUMO	0357	1083	0905	
YAMAHA	1773	0364	0388	0979
	0980	0370		
YAMAKAWA	0397	0392	0382	
YUKAI	0383			
ZENITH	0375	0907		

DVD-R

APEX	0911			
ARENA	0923			
ASPIRE	0952			
BLUE NOVA INTERNATIONAL	1051			
CENTRIOS	0951			
CMI	0923			
COBY	1051			
CYBERCOM	0923			
CYBERHOME	0912			
CYBERMAXX	0895	0905	0906	0923
	0959	1071	1117	
CYTRON	0895	0905	0906	0923
	0959	1071	1117	
DENVER	1051			
DUAL	0923			
ELTAX	1051			
EMERSON	1057			
GO-VIDEO	0383	1059	1061	
HITACHI	0387			
HB	1089			
ILO	0959			
JVC	1058	1072		
KENDO	0923			
LG	0907			
LIFE	1117			
LIFETEC	0895	0905	0906	0923
	0959	1071	1117	
LITEON	1056	1059	0959	
LUMATRON	1051			
MAGNAVOX	0979	0980		
MEDION	0895	0905	0906	0923
	0959	1071	1117	
MICROMAXX	0895	0905	0906	0923
	0959	1071	1117	
MICROSTAR	0895	0905	0906	0923
	0959	1071	1117	
MUSTEK	0383			
OCEANIC	1089			
PACKARD BELL	0940	1052		
PANASONIC	0403			
PHILIPS	0979	0980	1080	1128
PHOCUS	1063			
PIONEER	0977	1084		
PRO2	0895	0905	0906	0923
	0959	1071		
PROVISION	1051			
RTL	0923			
SAMPO	1051			
SAMSUNG	1112	1050		
SANYO	1060			
SCHAUB LORENZ	1089			
SHARP	1055			
SONY	0987	0988	0989	
TANGENT	1051			
TARGA	1115	0959	0891	1117
	0907	1121		
TCM	0923			
TELEDEVICE	1051			
TEVION	0890	0891	0895	0905
	0906	0923	0959	1065
	1071	1117		
THOMSON	0360	0359	1078	
TINY	1051			
TOSHIBA	0973	0983	0362	1111
TRANS-CONTINENTS	1051			
YAKUMO	0905			
YAMAHA	0979	0980		
ZENITH	0907			

TV-DVD(COMBOS)

AKAI	[1082&1410]			
AUDIOSONIC	[1062&0090]			
BEKO	1064			
BROKSONIC	0920			
CYBERCOM	[0343&0228]	[0924&0210]		
	[0933&0228]			
CYBERMAXX	[0343&0228]	[0924&0210]		
	[0933&0228]	0894		
CYTRON	[0343&0228]	[0924&0210]		

DUAL	[0933&0228]	0894		
	[0343&0228]	[0924&0210]		
	[0933&0228]			
DURABRAND	[0933&0228]	[1085&1006]		
	[1085&1007]	[1086&1008]		
	[1087&1008]	[1088&1009]		
H&B	[0343&0228]			
HB	[1089&1011]			
GERICOM	1064			
INTERTRONIC	0894			
LIFETEC	[0343&0228]	[0924&0210]		
	[0933&0228]	0894		
MEDION	[0343&0228]	[0924&0210]		
	[0933&0228]	0894	1001	
MEMOREX	0920			
MICROMAXX	[0343&0228]	[0924&0210]		
	[0933&0228]	0894		
MICROSTAR	[0343&0228]	[0924&0210]		
	[0933&0228]	0894		
MT LOGIC	[1062&0090]			
OCEANIC	[1089&1011]			
ORION	0920			
PHILIPS	[0339&0181]			
PHOCUS	1064			
PRO2	[0343&0228]	[0924&0210]		
	[0933&0228]	0894		
PROVIEW	1001			
SANSUI	0920			
SCHAUB LORENZ	[1089&1011]			
TCM	[0343&0228]	[0924&0210]		
	[0933&0228]	1119		
TEVION	[0343&0228]	[0924&0210]		
	[0933&0228]	1064	0894	
TOSHIBA	0920			
VESTEL	[1771&0215]			

DVD-VCR(COMBOS)

APEX	0949			
BROKSONIC	[0920&0967]			
CINEVISION	[0375&0256]			
CYBERCOM	0338	[0375&0256]		
CYBERMAXX	0338	0896	0906	
	[0375&0256]			
CYTRON	0338	0896	0906	
	[0375&0256]			
DAEWOO	0971			
DUAL	0338	[0375&0256]		
EMERSON	[0339&0231]	[0375&0256]		
FUNAI	[0339&0231]			
GO-VIDEO	0338	0367	0971	
GOLDSTAR	[0375&0256]			
HITACHI	[0387&0231]			
JVC	0400			
LG	0907	[0375&0256]		
LIFETEC	0338	0896	0906	
	[0375&0256]			
MAGNAVOX	[0914&0285]			
MEDION	0338	0896	0906	
	[0375&0256]			
MICROMAXX	0338	0896	0906	
	[0375&0256]			
MICROSTAR	0338	0896	0906	
	[0375&0256]			
PANASONIC	0970			
PHILIPS	[0969&0285]			
PIONEER	1084			
POLAROID	0949			
PRO2	0338	0896	0906	
	[0375&0256]			
SAMSUNG	0338	0963		
SANSUI	0920			
SANYO	[0378&0258]			
SILVERCREST	0256			
SONY	0402			
SYLVANIA	[0339&0231]			
TARGA	[0375&0256]	[0375&1041]		
	0907			
TCM	0338	[0375&0256]		
TEVION	0338	0896	0906	
	[0375&0256]			
TOSHIBA	0362			
ZENITH	[0375&0256]			

SAT					
@SAT	1147				
@SKY	1138				
ADECQ	1340				
AKAI	0552				
ALBA	0508	0562	0405	0407	
ALDES	0408	0409			
ALLSAT	0462	0410	0552		
ALLSONIC	0408	0428			
AMPERE	0422				
AMSTRAD	0584	0555	0541	0415	
	0416	0417	0419		
ANKARO	0408	0428	0424		
ANTTRON	0405	0407			
APOLLO	0405				
ARCOM	1174	1165			
ARCON	0415	0422	1155	1144	
	1153	0424	0463	1154	
ARENA	1222				
ARION	1238				
ARMSTRONG	0419				
ARNION	1147				
ASAT	0552				
ASCI	1138				
AST	0435				
ASTON	0594	0406			
ASTRA	0429	0419	0431	0432	
	0502				
ASTRO	0428	0439	0569	0407	
	0409				
AUDIOTON	0462	0407			
AURORA	0602				
AUSTAR	1224	0602	0643	0642	
AXIS	0428	0415	0432	0456	
BARCOM	0424				
BEST	0428	0424			
BLAUPUNKT	0439				
BOCA	0419	0502			
BRAIN WAVE	0444	0549	1131		
BRANDT	0565	0566	0567	0574	
BSKYB	0584	0555			
BT SATELLITE	0574				
BUSH	0508	0562	0410		
CANAL SATELLITE	0569	0599			
CANAL+	0569	0599			
CHAPARRAL	0507				
CHESS	0547	0586			
CITYCOM	0508	0640	0485	0459	
CLATRONIC	0444				
CLEMENS KAMPHUS	0491				
CNT	0409				
COLUMBUS	0477				
COMAG	1255	1237	1233	1231	
	0471				
COMMLINK	0408				
COMTECH	0456				
CONDOR	0428	0640			
CONNEXIONS	0438	0454			
CONRAD	0640	1156			
CONTEC	0456	0459			
COSAT	0462				
COSHIP	0427				
CROWN	0419				
CYBERCOM	0412	0413	0423	0428	
	0442	0493	0504	0511	
	0514	0546	0566	0583	
	0586	0587	0618	0619	
CYBERMAXX	0412	0413	0423	0428	
	0442	0466	0478	0484	
	0493	0504	0511	0514	
	0535	0546	0566	0583	
	0586	0587	0618	0619	
	0644	0650	0652	0653	
	1130	1138	1137		
	1130	1138	1137		
	0438				
DAERYUNG	0438				
DANSAT	0410				
D-BOX	0564	0604			
DECCA	0460				
DEW	0456				
DIAMOND	0461				
DIGIALITY	0640				
DIGIQUEST	1147	0485	0427		
DIGITAL M SERIE	1249				
DISKXPRESS	0424	0454			
DITRISTRAD	0462				
DMT	0412				
DNT	0438	0552			
DRAKE	0557	0463			
DREAMBOX	0658				
DREAM MULTIMEDIA	0658				
DSTV	0602				
DUAL	0412	0413	0423	0428	
	0493	0504	0511	0566	
	0583	0586	0587	0618	
	0514				
ECHOSTAR	0640	0581	0586	0425	
	0481	0578	0579	0580	
	0657	0659	0464	0465	
	0467				
EINHELL	0408	0417	0405	0419	
ELEKTA	0409				
ELTA	0428	0462	0405	0552	
EMANON	0405				
EMME ESSE	0428	0508	0491		
EMTECH	1162				
ENIGMA	1248				
EP SAT	0508	0491			
E-TEK	1140				
EUROPHON	0640				
EUROSAT	0419				
EUROSKY	0428	0640	1156	0419	
EUROSPACE	0468				
EUROSTAR	0438	0419			
EVA	0588	0589			
EXATOR	0405	0407			
FERGUSON	0508	0472	0603	0410	
	0473				
FIDELITY	0415	0417			
FINLANDIA	0508				
FINLUX	0508	0429	0608	0475	
	0480	0487			
FINNSAT	0603	0456			
FORCE	0577	0553	0535		
FORTEC STAR	0470				
FOXTEL	1224	1225	0602		
FOXTEL IQ	1225				
FRACARRO	0562				
FRANCE SATELLITE/TV	0477				
FREECOM	0405	0489			
FTE	0422	0496			
FUBA	0548	0439	0428	0438	
	0405	0424	0431	0477	
	0480	0552			
FUNTACH	0587				
GALAXIS	0428	0408	0462	0478	
	0484	0485	0535	0582	
	0583	0602	0619	0432	
	0456				
GALAXY	0424				
GLOBECAS	1141				
GLOBO	1156				
GMI	0419				
GOLDSTAR	0489				
GOODING	0483				
GOODMANS	0508				
GRANADA	0429				
GRANVISION	1235	1234			
GROTHUSEN	0405	0489			
GRUNDIG	0439	0436	0483	0495	
	0508	0544	0469	0602	
	0584	0407	0550		
HANDAN	0547	1167			
HANSEATIC	0504				

HANTOR	0444	0405			
HANURI	0409				
HB	1162	0413	1214	1215	
	1216				
HEAD	1253	1252	1251		
HELIOCOM	0422				
HIRSCHMANN	0439	0522	0547	0548	
	1156	1165	1174	0487	
	0488	0491	0558		
HISAWA	0444				
HITACHI	0508	0537			
HOMECAST	1222	1223	1162		
HOUSTON	0462				
HUMAX	1260	1259	1258	1250	
	0485	0517	0582		
HUTH	0408	0411	0444	0462	
	0419	0491			
HYUNDAI	0486				
ID DIGITAL	0485				
IMPERIAL	0562				
INNOVATION	0428	0493	0504	0511	
	0583	0586	0587	0618	
INTERTRONIC	0419				
INTERVISION	0462				
IRDETO	0602				
ITT/NOKIA	0429	0508	0548	0454	
	0487	0537			
JOHANSSON	0444				
JSR	0462				
JVC	0483				
KAON	1147				
KATHREIN	1221	1197	0549	0617	
	0631	0607	0635	0439	
	0459	0496	0507	0552	
KOSCOM	1144				
KOSMOS	0489	0491	0496		
KR	0407				
KREILING	0549	0631	1137	1232	
KREISELMEYER	0439				
KYOSTAR	0405				
LASAT	0428	0565	0566	0567	
	0630	1156	1157	0409	
	0502				
LENCO	0405	0489	0503		
LENG	0444				
LENNOX	0462				
LENSON	0479				
LG	0489				
LIFE	0583				
LIFESAT	0412	0413	0423	0428	
	0442	0493	0504	0511	
	0514	0546	0566	0583	
	0586	0587	0618	0619	
LIFETEC	0412	0413	0423	0428	
	0442	0466	0478	0484	
	0493	0504	0511	0514	
	0535	0546	0566	0583	
	0586	0587	0618	0619	
	0644	0650	0652	0653	
	1130	1138	1137		
LION	0468				
LORENTZEN	1156				
LORRAINE	0489				
LUPUS	0428				
LUXOR	0417	0429	0548	0537	
MACAB	0603				
MANHATTAN	0462	0508	0557	0633	
	0421	0409			
MARANTZ	0552				
MARMITEK	0641				
MARMITEK OCTOPUS	0655				
MASCOM	0409				
MASPRO	0483	0508	0507	0558	
MATSUI	0483	0574			
MB	0504				
MBOX	0442				
MEDIABOX	0569				
MEDIACOM	0506				
MEDIAMARKT	0419				
MEDIASAT	0569	0432			
MEDION	1257	1217	0412	0413	
	0423	0428	0442	0466	
	0478	0484	0493	0504	
	0511	0514	0535	0546	
	0566	0583	0586	0587	
	0618	0619	0644	0650	
	0652	0653	1130	1139	
	1138	1137	1181		
MEGA	0552				
METRONIC	0408	0575	0612	0613	
	0614	0615	0632	0409	
	0424	0405	0407		
METZ	0439				
MICRO TECHNOLOGY	0468				
MICROMAXX	0412	0413	0423	0428	
	0442	0466	0478	0484	
	0493	0504	0511	0514	
	0535	0546	0566	0583	
	0586	0587	0618	0619	
	0644	0650	0652	0653	
	1130	1139	1138	1137	
MICROSTAR	0412	0413	0423	0428	
	0442	0466	0478	0484	
	0493	0504	0511	0514	
	0535	0546	0566	0583	
	0586	0587	0618	0619	
	0644	0650	0652	0653	
	1130	1138	1137		
MINERVA	0483	0439			
mitsubishi	0508	0439	0574		
mitsumi	0502				
MORETV	0644	0423	1130	1181	
MORGAN SYDNEY	0611				
MORGANS	0611	0419	0502	0552	
MULTICHOICE	0602				
MULTISTAR	0496				
MULTITEC	0586	0587			
MURATTO	0437	0489			
NAVEX	0444				
NEC	0509	0510			
NEOTION	1138				
NEUHAUS	0462	0479	0432		
NEXTWAVE	0414	0585			
NIKKO	0419				
NOKIA	0530	0564	0425	0429	
	0508	0548	0563	0531	
	0454	0487	0604		
NOMEX	0622				
NORDMENDE	0549	0472	0508	0603	
	0405	0409			
NOVIS	0444				
OAK	0424				
OCEANIC	0461	0468			
OCTAGON	0405	0407	0456		
OKANO	0419	0491	0496		
OPTEX	0462	0459	0656		
OPTUS	1224	0602			
ORBIT	0435				
ORBITECH	0405				
ORIGO	0468				
OSAT	0407				
OTTO VERSAND	0439				
PACE	0584	0555	0439	0559	
	0527	0508	0410	0617	
	1225				
PACIFIC	0461				
PALCOM	0479	0431	0477		
PALLADIUM	0483	0419			
PALTEC	0431				
PANASONIC	0584	0508	0542		
PANDA	0508	0410			
PANSAT	0490				
PANTECH	0591				
PBI	1138				
PHILIPS	0552	0436	0483	0493	
	0495	0508	0543	0434	
	0569	0574	0605	0618	
	0455	0561	0550	0456	
	0515	0604			
PHOENIX	0456				

PHONOTREND	0408	0462	0491	0652					0546	0547	0586	0587
PILOTIME	0599								0588	0589	0590	0591
PINNACLE	0654								0592	0621	1140	1138
PIONEER	0569								1159	1161	1160	1162
POLSAT	0603								1167	1244	0636	1377
PREDKI	0444								1378	1379	1380	1381
PREMIER	0569								1382	1383	1384	
PREMIERE	0604	0569	0564	0542				SKYMAX	0552			
	0485	0462	0442					SKYPEX	1156			
PREMIUM X	1134							SKYPLUS	1138			
PRIESNER	0445	0419						SKYVISION	0462			
PRO2	0412	0413	0423	0428				SMART	1249	1248	1247	1246
	0442	0466	0478	0484					1244	1243	1241	1240
	0493	0504	0511	0514					1234	1174	1165	1133
	0535	0546	0566	0583				SM ELECTRONIC	0408	0412	0504	0506
	0586	0587	0618	0619					0546	0547	0586	0587
	0644	0650	0652	0653					0588	0589	0591	0621
	1130	1138	1137						1140	1138	0592	1159
PROFI	0503								1161	1160	1162	1167
PROMAX	0508								0636	1377	1378	1379
PROSAT	0408	0562							1380	1381	1382	1383
PROTEK	0461								1384			
PROVISION	0409							SONY	0584	0569	0418	0446
QUADRAL	0408	0428						SR	0472	0419	0502	
QUELLE	0439	0417						STARBOX	0427			
QUIERO	0603							STAR TRAK	0405			
RADIOLA	0552							STARLAND	0586			
RADIX	0630	0438	0632	1152				STARRING	0444			
RAINBOW	0407							STRONG	0562	0428	0602	0545
REDIFFUSION	0510								0454	0489	0405	0407
REDPOINT	0432							SUMIDA	0419			
REDSTAR	0428							SUNSTAR	0527	0419	0502	
RFT	0408	0552						TANDBERG	0603			
RUEFACH	0503							TANDY	0407			
SAB	1137	1144	1145	1146				TANTEC	0508	0479	0477	
	1147							TARGA	1195			
SABA	0472	0508	0543	0556				TATUNG	0460			
	0562	0565	0571	0572				TCM	0412	0413	0423	0428
	0573	0574	0575	0409					0442	0493	0504	0511
	0468								0514	0546	0566	0583
SABRE	0508								0586	0587	0618	0619
SAGEM	0570	0604	0599	0603				TECHNIHALL	0416			
	0648							TECHNISAT	1219	1220	0506	0438
	0456								0479	0569	0623	0528
SAKURA	0429	0527	0509	0520					0529			
SALORA	0426	0405	0506					TECHNOMATE	0441	1142		
SAMSUNG	0415	0435	0437					TECHNOTREND	1230	1173	1147	1131
SAT	0415	0435	0437					TECO	0419	0502		
SAT+	0546	1137						TELASAT	0640			
SATCOM	0640	0504	0523					TELEFUNKEN	0560	0508	0565	0566
SATEC	0508								0567	0574	0405	
SATPARTNER	0444	0405	0407	0409				TELEKA	0438	0640	0407	0419
	0489	0491						TELEMASTER	0409			
SCHAUB LORENZ	1147	1162	1214	1215				TELESAT	0504			
	1216							TELESTAR	1138	0479	0569	
SCHNEIDER	0428	0455	0506	0511				TELEVES	0508	0610	0611	
	0583	0586	0587	0618				TELEWIRE	0462			
SCHWAIGER	1255	1236	1233	1231				TEN HAAFT	0423			
	1157	1156	1131	0567				TEVION	0412	0413	0423	0428
	0565	0428	0409	0411					0442	0466	0478	0484
	0412	0413	0427	0430					0493	0504	0511	0514
	0433	0440	0504	0508					0535	0546	0566	0583
	0516	0566	0573	0575					0586	0587	0618	0619
	0576	0577	0582	0514					0644	0650	0652	0653
	0583	0585	0587	0598					1130	1140	1138	1137
	0616	0630	0631	0633				THOMSON	0472	0601	0570	0574
	0635	1132	1133	1147					0492	0508	0560	0568
	1152	1173	0459						0569	0603	0427	1156
SEEMANN	0438	0419	0432					THORENS	0461			
SEG	0428	0444	0504	0541				THORN	0508	0410	0473	
	0631	0634	0405					TIOKO	0459			
SELECO	0462							TONBURY	0445	1159		
SIEMENS	0439	1157						TONNA	0546	0508	0462	
SILVA	0489							TOPFIELD	1205	1204	1203	0497
SKARDIN	0432	0586	0546	1160					0505	0506		
SKY	0555	0584	1151					TPS	0570			
SKY DIGITAL	0584	0555						TPS PLATINUM	1178			
SKY+	0555							TRIAD	0435	0437	0533	0489
SKY HD	1151							TRIASAT	0480			
SKY ITALIA	0584	0555						TRIA X	0439	0479	0565	0609
SKYMASTER	0408	0412	0504	0506					0619			

TWINNER	0610	0611		
UNIDEN	0534			
UNISAT	0419	0456		
UNITOR	0444	0424		
UNIVERSUM	0439	0483	1156	0475
	0487			
VANTAGE	1254			
VARIOSTAT	0439			
VECTOR	0468			
VENTANA	0552			
VIA DIGITAL	0568			
VIA SAT	0568			
VISIOSAT	0594	0444	0462	0586
	0593	0595	0596	0597
VIVANCO	0536	0624		
VORTEC	0405			
V-TECH	0437	0435	0515	0537
WEVASAT	0508			
WEWA	0508			
WINERSAT	0444			
WISI	0435	0437	0438	0439
	0508	0533	0538	0539
	0540	0597	0625	0626
	0627	0628	0629	
WITTENBERG	0415			
WOORISAT	0409			
WORLDSAT	0631			
WYSI	1156			
XTREME	1147			
ZEHNDER	1137	1235	1234	1138
	0428	0437	0635	0541
	0631	0632	0409	0424
	0496			
ZINWELL	0485			
ZODIAC	0407			
CBL				
DILOG	1922			
DUNE	1924			
VIRGIN MEDIA	1917			

DVB-T

ADECQ	1226			
ALBA	0451	0646		
ARCOM	1242			
BUSH	1261	0647	0451	0032
BRAIN WAVE	0476			
CANAL +	1177			
CRYPTO	1919			
COMAG	1229			
CYBERMAXX	0645	0650		
CYTRON	0645	0650		
DIGENIUS	0645			
DIGIFUSION	0647			
DIGIHOME	1262			
DIGIO2	1150			
DIGIPAL	1218			
DMT	0412			
DURABRAND	0526			
ECHOSTAR	0657			
EMTECH	0476			
FREEBOX	1182			
FREEVIEW	0447	0451	0453	0457
	0482	0512	0513	0519
	0526	0532	0600	0646
	0647	0648	0649	0651
GbSAT	0476			
GERICOM	0443			
GOODMANS	1261	0526	0451	
GOODWAY	1163	1164		
GRUNDIG	0512	1172		
HAUPPAUGE	0482			
HB	1011	1211	1213	0476
HITACHI	1262	0526		
HOMECAST	0476			
HUMAX	0651			
INTERSTAR	0476			
JEPSSSEN	0476			
JVC	0526			
KATHREIN	1197			
LABGEAR	0513			
LASAT	1156			
LIDCOM	0451			
LIFETEC	0645	0650		
LOGIK	1263			
MARMITEK OCTOPUS	0655			
MATSUI	0649	0526	0451	
MEDION	0645	0650		
MICO	1135			
MICROMAXX	0645	0650		
MICROSTAR	0645	0650		
NOKIA	0519	0531		
NOOS	1183			
OCEANIC	1011			
OGGLE	1136			
ON-DIGITAL	0527	0531	0620	
OPTEX	0656			
PACE	0453	0527		
PACIFIC	0526			
PANASONIC	0072	0403		
PHILIPS	0600			
PIONEER	0457	0620		
PREMIERE	0600	0519		
PRO2	0645	0650		
REBOX	0476			
SAGEM	0648	1143		
SCHAUB LORENZ	1011	1211	1212	1213
	0476			
SCHWAIGER	1156	1229	1173	0630
SHARP	0059			
SKARDIN	0656			
SKYMASTER	1166	1165	1164	1163
	1140	0656	0412	
SMART	1247	1245	1242	1165
	1133			
SM ELECTRONIC	0412	0656	1165	1163
	1164			
SONY	0447			
TCM	1413	1017	1119	
TECHNIKA	1262			
TECHNISAT	1218			

TECHNOTREND	1173		
TELEVES	0476		
TEVION	0645	0650	
THOMSON	0427	0532	
TOPFIELD	1204	0506	
TOP-UP TV	0527	0531	0657
TVONICS	1263		
WHARFEDALE	1262		
WORLDSAT	0476		
YUNG FU	1166		

Audio Amplifiers. Tuners. Receivers

CENTRUM	0692			
CRITERION	0775			
CYBERCOM	0841	0775	0776	
CYBERMAXX	0841	0775	0776	
CYTRON	0841	0775	0776	
DENON	1048	0779	0781	
DUAL	0841	0775	0797	
ELTA	0667	0668		
GRUNDIG	0697	0698	0727	
HARMON/KARDON	0682			
KENWOOD	0761			
LIFETEC	0841	0775	0776	
LINN	0857			
MARANTZ	0727			
MEDION	0841	0775	0776	
MICROMAXX	0841	0775	0776	
MICROSTAR	0841	0775	0776	
NAD	0735	0736	0737	0738
	0799	0800		
NUVO	0862	0863	0864	0865
ONKYO	0785	0792	0793	0826
PHILIPS	0734	0846	0727	
PRO2	0841	0775	0776	
SANSUI	0727			
SCHNEIDER	0791			
SHERWOOD	0782			
SONY	0739	0740	0755	0757
	0758	0759	0760	
TCM	0841	0775	0776	0806
TEAC	0794	0796		
TECHNICS	0764	0777	0788	
TEVION	0775	0776	0815	0817
	0841			
THEORIE & ANWENDING	0805			
THOMSON	0842	0766		
XANTECH	0867			
YAMAHA	0883	0882	0839	0838
	0724	0752	0770	0771
	0772			

Audio Tape Players

AIWA	0790			
DENON	0780			
GRUNDIG	0729	0698		
HARMON KARDON	0681			
KENWOOD	0761			
MAGNAVOX	0729			
MARANTZ	0729			
NAD	0799			
ONKYO	0784			
PHILIPS	0729			
SANSUI	0729			
SHERWOOD	0783			
SONY	0754	0755	0756	
TEAC	0794			
TECHNICS	0764	0777	0786	
THOMSON	0842			
YAMAHA	0724	0772		

MINI Systems

AIWA	0773	0774		
CYBERCOM	0852	0858	0704	0745
	0808	0810	0820	0819
CYBERMAXX	0852	0858	0704	0745
	0808	0810	0811	0812
	0820	0819		
CYTRON	0852	0858	0704	0745
	0808	0810	0811	0812
	0820	0819		
DUAL	0852	0858	0704	0745
	0797	0820	0819	
E-BENCH	0811			
ELTA	0693	0745		
GRUNDIG	0707			
INSIGNIA	0731			
INTERTRONIC	0811			
LIFE	0879	0823	0811	
LIFETEC	0879	0823	0852	0858
	0704	0745	0808	0810
	0811	0812	0820	0819

MEDION	0879	0823	0731	0728
	0852	0858	0704	0745
	0808	0810	0811	0812
	0820	0819		
MICROMAXX	0852	0858	0704	0745
	0808	0810	0811	0812
	0820	0819		
MICROSTAR	0852	0858	0704	0745
	0808	0810	0811	0812
	0820	0819		
PIONEER	0753			
PRO2	0852	0858	0704	0745
	0808	0810	0811	0812
	0820	0819		
	0768			
SHARP	0768			
SILVERCREST	0828	0811	0829	0868
SONY	0741			
TCM	0879	0880	0852	0858
	0704	0745	0808	0810
	0811	0820	0819	0694
	0823	0824	0825	
TEVION	0879	0823	0852	0858
	0704	0745	0808	0810
	0811	0812	0820	0819
	0821	0822		
WELLTECH	0881	0852	0810	0820
	0819	0694	0803	0811
	0827			

Misc.

APPLE IPOD	0885			
AUDIO COMBI	0844			
CAR RADIO	0861			
CDR	0847	0675		
DBS	0845			
INTERNET RADIO	0670			
HAMA INTERNET RADIO	1906			
IPOD	0884			
SWITCH BOX	0684			
VIDEO CD	0840			

AUD

DVICO	1918			
GOOGLE	1907			

SOUNDBAR

HAMA	1925			
LOGIK	1904			
SANDSTROM	1905			
SONY	1903			

STREAMING

DVICO	1918			
SONY	1923			
WD	1920			
XBMC	1921			

hama®

**Hama GmbH & Co KG
86652 Monheim / Germany
www.hama.com**

All listed brands are trademarks of the corresponding companies.
Errors and omissions excepted, and subject to technical changes.
Our general terms of delivery and payment are applied.