

# ***hama***®

THE SMART SOLUTION

## 电视支架



# ***hama***®

亚玛贸易(深圳)有限公司  
中国深圳市福田区福华三路  
88号时代财富大厦32H

HAMA Trading (Shenzhen) Co., Ltd.  
32H, Shidai-Caifu Building,  
No.88 Fuhuasan Road, Futian District,  
Shenzhen, China, 518026

**Hama GmbH & Co KG**  
**D-86651 Monheim/Germany**  
[www.hama.com](http://www.hama.com)

C1096041/02.11

All listed brands are trademarks of the corresponding companies. Errors and omissions excepted, and subject to technical changes. Our general terms of delivery and payment are applied.

**C1096041**

## 内容：

- 1.说明书注释
  - 2.预期用途及技术参数
  - 3.零件清单
  - 4.警告及安全说明
  - 5.安装
  6. 操作&维护
  - 7.联系方式
- 

### 1.说明书注释

本说明书在本设备的整个服务期限内都适用，请将其传给随后的使用者或所有者。

---

### 2.用途及技术参数

电视支架用来支撑带DVD播放器、接收器以及扩音器等的平板显示器。

设计：电视柜

推荐屏幕尺寸：96.0 – 160.0 cm (美国：37" – 65")

材料：玻璃/铝

搁架载荷能力：最大20 kg

底座载荷能力：最大20 kg

墙装托架载荷能力：最大40 kg

宽度：90 cm

高度：125 cm

深度：42,5 cm

---

### 3. 零件清单

参见第3页。

---

### 4. 警告及安全说明

安装电视支架前请联系有资质的专业人员。安装前请检查电视支架是否完整并确保没有部件有瑕疵或者损坏。本电视支架只能用于预期目的。确保电视机周围有50cm的安全空间（取决于型号）。

电视支架安装完成之后，检查是否足够安全，能否使用。您应该定期重复此检查（至少每三个月一次）。假如出现损坏，移除设备，不要继续使用电视机支架。必须在第二个人的帮助下安装电视支架。安装期间确保电线没有踩坏或者损坏。请勿将重于额定载重量的物体置于电视支架上，并且不要超过规定最大屏幕尺寸。确保电视支架安装对称。

Hama GmbH & Co. KG不接受由于错误安装支架及其产生的损害而要求的保证期索赔。

---

### 5. 安装

请遵守本警告及安全说明。

安装时请参阅第4-6页的图解说明。

---

### 6. 操作&维护

电视支架安装无须任何工具。

定期检查托架是否安全（至少每3个月）。只能用清水或者标准家用清洁剂清洁。

---

### 7. 联系方式

如有疑问，请与经销商或Hama产品顾问联系。

电子邮件：service@hama.asia

---